


Hello Finger 設定流程

首先,插上 Hello Finger



TARTEK

至 [開始]功能表並選取 [設定]







點選[帳戶]



Windows Settings





System ay, notifications, apps



Devices



Personalizatio Background, lock so





Time & languag



Ease of Access Narrator, magnifier, hig contrast




Privacy Location, camera



Update & security Windows Update, recover




點選[登入選項]








點選[設定]










用欲建檔的手指接壓 Hello Finger









設定過程中必須來回按壓數次,直到顯示設定完成,即可開始使用指紋登入功能

